Lab Part 2

- 1. Write a function to calculate included angle from two vectors
- 2. Identify center of mass (com) position vs. time or 2. Identify gait speed vs. time
- 3. Identify ankle height vs. time (R, L)
- 4. Identify knee angle vs. time (R, L)
- 5. Set up pandas dataframe with outcome variables
- 6. Code rows in dataframe by participant
- 7. Plot the data

What to turn in

- 1. A completed notebook with documented code
- 2. The aggregated csv file

OpenPose Demo

- 1. Submit a photo/video of yourself being keypoint detected.
- 2. Submit the command line call you would use to have openpose perform keypoint detection on a sample .avi file and write the .json results to a directory in of a video itself.

```
In [1]: # imports etc.
    import validators
    from pathlib import Path
    import urllib.request
    import numpy as np
    import pandas as pd
    import json
    import seaborn as sns
    import math
    import os
    import glob
    from scipy import ndimage
    #import requests
    import matplotlib.pyplot as plt
    sns.set_theme()
```

```
In [3]: | ## Base functions for interacting with .json files
         # The following routines allow you to load and make a basic plot of a `.json`
         file from OpenPose.
         def extract_kp_from_resource(f,person_id = -1):
             Extract keypoints from resource (file or url) as a numpy vector
             if validators.url(f):
                 json temp = json.load(urllib.request.urlopen(u))['people']
             if Path(f).exists():
                 json temp = json.load(open(f))['people']
             try:
                 # extract the keypoints of the person specified by person id; default
          is last person identified
                 keypoints = np.array(extract kp from json(json temp)["pose keypoints 2
         d"][person id]).astype('float')
             except:
                 keypoints = np.empty((75,))
                 keypoints[:] = np.NaN
             # set missing points (imputed as 0) to nan so that they are not plotted
             keypoints[keypoints==0] = np.nan
             return keypoints
         def extract_kp_from_json(json_people):
             subfunction for extract kp from resource
             person id = []
             pose keypoints 2d = []
             for i in range(0,len(json_people)):
                 person_id.append(json_people[i]["person_id"])
                 pose keypoints 2d.append(json people[i]["pose keypoints 2d"])
             # return a dict
             return {'person id': person id, 'pose keypoints 2d': pose keypoints 2d}
         def convert_kp_to_df(keypoints):
             reshape keypoint vector to dataframe
             # reshape to 25 X 3; the coordinates are x, y, confidence in estimate
             kin = keypoints.reshape((-1,3))
             # create a dataframe
             df = pd.DataFrame({'keypoint': ["Nose", "Neck", "RShoulder", "RElbow", "RW
         rist", "LShoulder", "LElbow", "LWrist", "MidHip", "RHip", "RKnee", "RAnkle", "LHip", "LKnee", "LAnkle", "REye", "LEye", "REar", "LEar", "LBigToe", "LSmallT
         oe", "LHeel", "RBigToe", "RSmallToe", "RHeel"], 'x': kin[:,0], 'y': kin[:,1],
         'confidence': kin[:,2]})
             return df.set index('keypoint')
```

```
def plot_body25_df(df):
    """
    plot a dataframe corresponding to body25 coordinates
    """
    segments = [['Neck', 'REar', 'LEar', 'Neck'],
        ['Nose', 'REye', 'LEye', 'Nose'],
        ['RShoulder', 'Neck', 'LShoulder', 'RShoulder'],
        ["LShoulder", "LElbow", "LWrist"],
        ["RShoulder", "RElbow", "RWrist"],
        ['RShoulder', 'RHip', 'LHip', 'LShoulder', 'RShoulder'],
        ['LHip', 'MidHip', 'RHip'],
        ["LHip", "LKnee", "LAnkle"],
        ["RHip", "RKnee", "RAnkle"],
        ["RHip", "RKnee", "RAnkle"],
        ['RAnkle', 'LHeel', 'LBigToe', 'LSmallToe', 'LAnkle']]

fig, ax = plt.subplots()
    ax.set(xlim=[0, 1920], ylim=[1080, 0], xlabel='X', ylabel='Y')
    [sns.lineplot(data=df.loc[s].reset_index(), x = "x", y = "y", ax = ax) for
s in segments]
```

```
In [4]:
        # function to calculate the outcomes of the dataset:
        def angle_between(v1, v2):
            Returns the angle in degrees between two vectors v1 and v2:
            v1 = np.asarray(v1)
            v2 = np.asarray(v2)
            v1 u = v1 / np.linalg.norm(v1)
            v2 u = v2 / np.linalg.norm(v2)
            return math.degrees(np.arccos(np.clip(np.dot(v1 u, v2 u), -1.0, 1.0)))
        def df to outcomes(folder, Frames, data, files):
            #Return a dataframe with kinematic outcomes derived from a single body 25
         dataframe
             .....
            folder = folder.replace("\\","/")
            for i in range(len(Frames)):
                #print(folder)
                #'Right Ankle Hight
                 Frame = Frames[i]
                 FileName =os.path.basename(Frame)
                 FrameName =os.path.basename(Frame).split("_")[1]
                data['Folder Name'].append(folder)
                data['File Name'].append(FileName)
                 data['Frame Number'].append(FrameName.lstrip('0'))
                #data['Frame Number'].append(FrameName.lstrip('0')+"/"+str(len(Frame
        s)))
                 calc outcomes(folder, FileName)
            return data
        def calc outcomes(folder, fileName):
            Calculate outcomes from a file or other resource
            return as a dataframe in a standerd formate
            dirctory = folder+"/"+fileName
            kp_u = extract_kp_from_resource(dirctory)
            #print(dirctory)
            kp f = extract kp from resource(fileName)
            df u = convert kp to df(kp u)
            df_f = convert_kp_to_df(kp_f)
            F=df u
        # Right Knee Angle:
            RHipx=F.iloc[9]['x'] #RHip[9], RKnee[10], RAnkle[11]
            RHipy=F.iloc[9]['y']
            RKneex=F.iloc[10]['x']
            RKneey=F.iloc[10]['y']
            RAnklex=F.iloc[11]['x']
            RAnkley=F.iloc[11]['y']
            v1R = (RHipx-RKneex, RHipy -RKneey)
            v2R = (RKneex-RAnklex, RKneey-RAnkley)
```

```
RkneeAngle=angle between(v1R, v2R)
# Left Knee Angle:
   LHipx=F.iloc[12]['x'] #LHip[12], LKnee[13], LAnkle[14]
   LHipy=F.iloc[12]['y']
   LKneex=F.iloc[13]['x']
   LKneey=F.iloc[13]['y']
   LAnklex=F.iloc[14]['x']
   LAnkley=F.iloc[14]['y']
   v1L = (LHipx-LKneex, LHipy -LKneey)
   v2L = (LKneex-LAnklex, LKneey-LAnkley)
   LkneeAngle=angle between(v1L, v2L)
# Calculate Ankle Hight
   RAnkleHight=RAnkley-F.min()['y']
   LAnkleHight=LAnkley-F.min()['y']
# Calculate center of mass (COM):
# Calculate center of mass (COM):
   F=F.dropna()
   xy=F[['x','y']]
   com = tuple(np.mean(xy))
   x=com[0]
   y=com[1]
   data['Right knee Angle'].append(RkneeAngle)
   data['Left knee Angle'].append(LkneeAngle)
   data['Right Ankle Height'].append(RAnkleHight)
   data['Left Ankle Height'].append(LAnkleHight)
   data['Center of Mass (com)-x'].append(x)
   data['Center of Mass (com)-y'].append(y)
```

```
In [5]: for folder in Folders:
    Frams = glob.glob(folder+"/*.json")
    df_to_outcomes(folder, Frams, data, files)
    outcomes = pd.DataFrame(data)
    outcomes
```

Out[5]:

	Folder Name	File Name	Frame Number	Right knee Angle	Left knee Angle	Right Ankle Height	Left Ankle Height	Cent (cc
0	json/json/1, 10-25, Normal gait, Sag, Paige	f_0000000000000_keypoints.json		NaN	NaN	NaN	NaN	7.80
1	json/json/1, 10-25, Normal gait, Sag, Paige	f_000000000001_keypoints.json	1	NaN	NaN	NaN	NaN	10.55
2	json/json/1, 10-25, Normal gait, Sag, Paige	f_000000000002_keypoints.json	2	NaN	0.026289	NaN	500.247	11.18
3	json/json/1, 10-25, Normal gait, Sag, Paige	f_000000000003_keypoints.json	3	NaN	0.024306	NaN	503.207	9.58
4	json/json/1, 10-25, Normal gait, Sag, Paige	f_0000000000004_keypoints.json	4	NaN	0.065731	NaN	370.929	9.47
3370	json/json/9, 10-25 Circum hip L gait, Sag, Paige	f_000000000169_keypoints.json	169	NaN	NaN	NaN	NaN	
3371	json/json/9, 10-25 Circum hip L gait, Sag, Paige	f_000000000170_keypoints.json	170	NaN	NaN	NaN	NaN	
3372	json/json/9, 10-25 Circum hip L gait, Sag, Paige	f_000000000171_keypoints.json	171	NaN	NaN	NaN	NaN	
3373	json/json/9, 10-25 Circum hip L gait, Sag, Paige	f_000000000172_keypoints.json	172	NaN	NaN	NaN	NaN	
3374	json/json/9, 10-25 Circum hip L gait, Sag, Paige	f_000000000173_keypoints.json	173	NaN	NaN	NaN	NaN	


3375 rows × 9 columns

```
In [18]: #Sample load and plot
             "ison/ison/1, 10-25, Normal gait, Sag, Paige/f_00000000100_keypoints.jso
         f = 'f 00000000100 keypoints.json'
         kp_u = extract_kp_from_resource(u)
         kp f = extract kp from resource(f)
         df u = convert kp to df(kp u)
         df f = convert kp to df(kp f)
         plot body25 df(df u)
         #angle_between(F.loc[:,"x"].values, F.loc[:,"y"].values)
         F=df u
         # Right Knee Angle:
         RHipx=F.iloc[9]['x'] #RHip[9], RKnee[10], RAnkle[11]
         RHipy=F.iloc[9]['y']
         RKneex=F.iloc[10]['x']
         RKneey=F.iloc[10]['y']
         RAnklex=F.iloc[11]['x']
         RAnkley=F.iloc[11]['y']
         v1R = (RHipx-RKneex, RHipy -RKneey)
         v2R = (RKneex-RAnklex, RKneey-RAnkley)
         RkneeAngle=angle_between(v1R, v2R)
         # Left Knee Angle:
         LHipx=F.iloc[12]['x'] #LHip[12], LKnee[13], LAnkle[14]
         LHipy=F.iloc[12]['y']
         LKneex=F.iloc[13]['x']
         LKneey=F.iloc[13]['y']
         LAnklex=F.iloc[14]['x']
         LAnkley=F.iloc[14]['y']
         v1L = (LHipx-LKneex, LHipy -LKneey)
         v2L = (LKneex-LAnklex, LKneey-LAnkley)
         LkneeAngle=angle between(v1L, v2L)
         print("Right knee Angle:",RkneeAngle, ",Left knee Angle:",LkneeAngle)
         # Ankle Hight:
         RAnkleHight=RAnkley-F.min()['y']
         LAnkleHight=LAnkley-F.min()['y']
         print("Right Ankle Hight:",RAnkleHight, ",Left Ankle Hight:",LAnkleHight)
         # Calculate center of mass (COM):
         F=F.dropna()
         xy=F[['x','y']]
         com = tuple(np.mean(xy))
         print(com[0],com[1])
```

Right knee Angle: 1.0192452811899542 ,Left knee Angle: 15.634537391150769


Right Ankle Hight: 494.458 ,Left Ankle Hight: 485.636

987.134695652174 574.2872608695652




```
In [13]: # Plot Right Knee Angle Vs. Time
    g = sns.FacetGrid(outcomes, row="Folder Name",sharex=False)
    g.map(sns.lineplot, "Frame Number", "Right knee Angle")
    g.set(xticklabels=[])
    plt.savefig('RightkneeAngle.png',dpi=300, bbox_inches='tight')
```


Folder Name = json/json/1, 10-25, Normal gait, Sag, Paige




Folder Name = json/json/10, 10-25, Trendel gait, Sagittal, Paige



Folder Name = json/json/11, 10-25, Vaulting gait opposite side, Sag, Paige




Folder Name = json/json/2, 10-25, Normal gait, Sag, Zach




Folder Name = json/json/3, 10-25, R Hemi gait, Sag, Zach







Folder Name = json/json/4, 10-25, Vaulting gait, Sag, Paige




Folder Name = json/json/5, 10-25, Crouch Gait, Sag, Zach




Folder Name = json/json/6, 10-25, Circum hip gait, Paige




Folder Name = json/json/7, 10-25, Ataxic gait, Sag, Zach



Folder Name = json/json/8, 10-25, Limping gait, Sag, Zach




Folder Name = json/json/9, 10-25 Circum hip L gait, Sag, Paige




Frame Number

```
In [14]: # Plot Left Knee Angle Vs. Time
    g = sns.FacetGrid(outcomes, row="Folder Name",sharex=False)
    g.map(sns.lineplot, "Frame Number", "Left knee Angle")
    g.set(xticklabels=[])
    plt.savefig('LeftkneeAngle.png',dpi=300, bbox_inches='tight')
```


Folder Name = json/json/1, 10-25, Normal gait, Sag, Paige




Folder Name = json/json/10, 10-25, Trendel gait, Sagittal, Paige



Folder Name = json/json/11, 10-25, Vaulting gait opposite side, Sag, Paige




Folder Name = json/json/2, 10-25, Normal gait, Sag, Zach




Folder Name = json/json/3, 10-25, R Hemi gait, Sag, Zach 80







Folder Name = json/json/4, 10-25, Vaulting gait, Sag, Paige 80




Folder Name = json/json/5, 10-25, Crouch Gait, Sag, Zach




Folder Name = json/json/6, 10-25, Circum hip gait, Paige




Folder Name = json/json/7, 10-25, Ataxic gait, Sag, Zach



Folder Name = json/json/8, 10-25, Limping gait, Sag, Zach




Folder Name = json/json/9, 10-25 Circum hip L gait, Sag, Paige




Frame Number

```
In [15]: # Plot Right Ankle Hieght Vs. Time
    g = sns.FacetGrid(outcomes, row="Folder Name", sharex=False)
    g.map(sns.lineplot, "Frame Number", "Right Ankle Height")
    g.set(xticklabels=[])
    plt.savefig('RightAnkleHieght.png',dpi=300, bbox_inches='tight')
```


Folder Name = json/json/1, 10-25, Normal gait, Sag, Paige




Folder Name = json/json/10, 10-25, Trendel gait, Sagittal, Paige



Folder Name = json/json/11, 10-25, Vaulting gait opposite side, Sag, Paige



Folder Name = json/json/2, 10-25, Normal gait, Sag, Zach




Folder Name = json/json/3, 10-25, R Hemi gait, Sag, Zach







Folder Name = json/json/4, 10-25, Vaulting gait, Sag, Paige




Folder Name = json/json/5, 10-25, Crouch Gait, Sag, Zach



Folder Name = json/json/6, 10-25, Circum hip gait, Paige




Folder Name = json/json/7, 10-25, Ataxic gait, Sag, Zach



Folder Name = json/json/8, 10-25, Limping gait, Sag, Zach




Folder Name = json/json/9, 10-25 Circum hip L gait, Sag, Paige




Frame Number

```
In [16]: # Plot Left Ankle Hieght Vs. Time
    g = sns.FacetGrid(outcomes, row="Folder Name", sharex=False)
    g.map(sns.lineplot, "Frame Number", "Left Ankle Height")
    g.set(xticklabels=[])
    plt.savefig('LeftAnkleHieght.png',dpi=300, bbox_inches='tight')
```


Folder Name = json/json/1, 10-25, Normal gait, Sag, Paige




Folder Name = json/json/10, 10-25, Trendel gait, Sagittal, Paige



Folder Name = json/json/11, 10-25, Vaulting gait opposite side, Sag, Paige



Folder Name = json/json/2, 10-25, Normal gait, Sag, Zach




Folder Name = json/json/3, 10-25, R Hemi gait, Sag, Zach







Folder Name = json/json/4, 10-25, Vaulting gait, Sag, Paige




Folder Name = json/json/5, 10-25, Crouch Gait, Sag, Zach



Folder Name = json/json/6, 10-25, Circum hip gait, Paige




Folder Name = json/json/7, 10-25, Ataxic gait, Sag, Zach



Folder Name = json/json/8, 10-25, Limping gait, Sag, Zach




Folder Name = json/json/9, 10-25 Circum hip L gait, Sag, Paige




Frame Number

```
In [17]: #plot The Center of Mass over time in every folder:
    g = sns.FacetGrid(outcomes, row="Folder Name", sharex=False)
    g.map(sns.scatterplot, "Center of Mass (com)-x", "Center of Mass (com)-y")
    g.set(xticklabels=[])
    plt.savefig('comvstime.png',dpi=300, bbox_inches='tight')
```


Folder Name = json/json/1, 10-25, Normal gait, Sag, Paige




Folder Name = json/json/10, 10-25, Trendel gait, Sagittal, Paige




Folder Name = json/json/11, 10-25, Vaulting gait opposite side, Sag, Paige




Folder Name = json/json/2, 10-25, Normal gait, Sag, Zach




Folder Name = json/json/3, 10-25, R Hemi gait, Sag, Zach







Folder Name = json/json/4, 10-25, Vaulting gait, Sag, Paige




Folder Name = json/json/5, 10-25, Crouch Gait, Sag, Zach




Folder Name = json/json/6, 10-25, Circum hip gait, Paige




Folder Name = json/json/7, 10-25, Ataxic gait, Sag, Zach



Folder Name = json/json/8, 10-25, Limping gait, Sag, Zach 800



Folder Name = json/json/9, 10-25 Circum hip L gait, Sag, Paige



Center of Mass (com)-x

```
In [12]: # Write the data to a `csv` file
    outcomes.to_csv("outcomes.csv",index=False)
```

Running OpenPose on Windows using powershell:

A video of running the command line using the demo, a zip file for the results of a personal video (json files, video with keypoint) were submitted.

```
In [ ]: # Command Line of openpose to preform keypoint detection on a personal video a
    nd saving the video with keypoint(live iphone image)
    bin\OpenPoseDemo.exe --video examples/media/InNYRita.avi --write_video NYRitew
    keypoint.avi
    # Command Line of openpose to save the .json files:
    bin\OpenPoseDemo.exe --video examples/media/InNYRita.avi --num_gpu 0 --write_v
    ideo InNYRita_output/result.avi --write_json InNYRita_output/
```